

Fitting Guide Outside Recess Shutters



Fitting Instructions (**Outside Recess Shutters**)

How to Fit Your *Shutters*



SIMPLE STEPS

Fitting guide – outside recess shutters


Fitting Time: Approx. 1 hour.

WARNING: Please read these instructions fully before starting.

What you'll need

<p>Screwdriver</p> 	<p>Drill</p> 	<p>Rubber mallet</p> 	<p>Correct screws and wall plugs (depending on surface)</p> 
<p>Spirit level (recommended)</p> 	<p>Packing material such as wedges or cardboard (recommended)</p> 	<p>Decorators caulk (optional, for finishing)</p> 	


What's in the box

<p>Shutter panels</p> 	<p>Frame pieces</p> 	<p>Screws</p> 	<p>Hinges</p> 
<p>Hinge packers</p> 	<p>Hinge pins</p> 	<p>Plastic Hoffman keys</p> 	<p>Small drill cover caps</p> 

Note: This installation should be carried out by someone confident in DIY.


Step 1 – Assemble the frame

Lay out the frame pieces on the floor. The ends are mitred to fit together. Join the frame corners using the Hoffman keys in the bowtie-shaped slots. Tap gently with a rubber mallet until flush.




Step 2 – Position the frame outside the recess

Lift the assembled frame and place it against the wall, outside the recess. Use a spirit level to ensure it is plumb and level. Check the frame sits evenly around the window opening.




Step 3 – Fix the frame

Mark fixing points through the pre-drilled holes. Remove the frame, drill holes, and insert wall plugs. Reposition the frame and secure it to the wall with screws.



Step 4 – Attach the panels

Position the shutter panels inside the frame. Insert the hinge pins to secure each panel. Use hinge packers if needed for alignment.



Step 5 – Check operation

Open and close each panel to confirm smooth movement. Adjust packing if necessary to correct alignment.

Step 6 – Finishing touches

Insert cover caps over drill holes. Apply decorators caulk around the outside edge if required for a neat finish.

